


Assembly Instructions: Diego Table Top

PARTS LIST

A Drill Bit



B Screw
M4x16



C Washer



ASSEMBLY TIP

To protect your table top from scratches during assembly, please assemble on the cardboard box.

Before you begin, gather the following:

- Table top & Table base
- 2.5mm Allen key
- Screws and drill bit listed above
- Drill (use on low speed)
- Measuring tape (to help centre the base)



Step 1: Position the table base upside down and align it centrally on the tabletop.

Step 2: Mark the hole positions for your base.

Remove the base and drill your pilot holes, taking care to match the depth of the existing holes.

NOTE: place the drill bit into the pre-drilled hole on the table top and attach tape to the drill bit as a depth guide to ensure you don't drill through the tabletop.

Step 3: Place the base onto your top and secure it using the screws. Once fixed, carefully flip the table upright.

NOTE: Do not overtighten screws. Do not use an electric drill to secure screws.

Step 4: Final adjustments:

If the table feels uneven, adjust the feet on the base and check that all screws are securely tightened.

Thank you for your purchase.

Pablo table tops and bases are exclusively supplied by Chairforce.

To learn more about our products please visit www.chairforce.com.au and www.chairforce.co.nz

AU: Call: 08 9436 8570 Email: customercare@brayco.com.au

NZ: Call: 09 271 5000 Email: sales@chairforce.co.nz

